



Digital Photo Printer **DS-SL20**

How to use:
Expansion Printer




Expansion Printer Connectivity

DS-SL20

Features and System Configurations

The DS-SL20 can connect to an expansion printer and use it as a slave printer. The expansion printer can print on media sizes that the DS-SL20 doesn't support, which means shop owners can provide customers with two print sizes without having to replace the paper media.



Printer and Print Size

Compatible printer and print size are as follows.

Printer	Print Size		Image Size (Pixels)
DS80	4x8"	203x100 mm	2448 x 1236
	8x10"	203x254 mm	3036 x 2448
	8x12"	203x305 mm	3636 x 2472




Using the DS80 as an expansion printer

DS-SL20

System Requirements

Please use a USB cable to connect the DS-SL20 and the DS80. Plug the USB cable into the USB (A) port (host) on the top of the DS-SL20. For further details on connection, refer to the operating instructions for your printer.



Notes

- Only one expansion printer can be connected to the DS-SL20.
- When printing "3up 4x8 photo card", setup "Cut mode" in administration menu with connecting DS80.
- "Express Print", "Index Print" and "Split Images" are not available when printing 8x10" and "8x12"
- Watermark (design, order number and file name) is not available.
- Color adjustment of the DS80 is available from the DS-SL20's administration menu.
(Gray balance adjustment is not supported.)